

PRODECRAN
345 RUE DE L'INDUSTRIE
Z.I. DU VERMEILLET
30380 SAINT-CHRISTOL LES ALES
France (EEC)

Tel.: (+33) 4 66 60 90 50 Fax: (+33) 4 66 60 94 09

TECHNICAL DATA SHEET

PRODUCT
Date: 04/03/15

Page 1 to 1
Version 5

1. PRODUCT DESCRIPTION

Alkaline paste used to eliminate ghosts images.

Shelf life: 2 years at 20°C.

2. APPLICATION

This haze remover can be used on all non-metallic mesh.

3. *USE*

PROPASTE is a very corrosive product, consequently wear gloves, goggles and protective clothes.

MIXTURE:

Stir to get a smooth consistency.

APPLY ON THE SCREEN:

With a pencil, apply the product if possible on both sides of the screen. This product may weaken the mesh (above all when applied on worn mesh or on fine mesh) so it is recommended not to leave it on the screen than 15 minutes for the first application. If the result is not satisfactory, leave it on the screen another 15 minutes and go on further until screen is white. It is important not to dry the screen in an oven.

4. FIRST AID PROCEDURES

INHALATION: None.

EYES CONTACT: Rinse immediately with plenty of water, also under the eyelids, for at least 15 minutes.

In the event of persistent irritation or any lesions, consult an oculist.

SKIN CONTACT: Wash off with soap and water.

INGESTION: Clean mouth with water. Ask for medical immediately.

5. SUPPLIED IN

1 KG



5 KG



30 Kg



TDS PROPASTE www.prodecran.com